

## 1 piece studded mesh grille for Dodge grille 1500-3500

*In kit- 4 brackets, 8 stainless bolts, and 12 stainless lock nuts  
tools- ¼ drill bit, 11mm wrenches, sharpie, cut off wheel or any type of saw (to cut the frame).*

**Set Grille on a padded surface.**

1. Remove OEM grille frame from truck. (about 8-10 8mm bolt and nuts)
2. Cut center out of the grille frame. Leaving a outer border for OKF grille to bolt to.
3. Mock OKF Grille up using the 4 studs on the outer edges of the grille (only finger tighten)
4. Mark the holes BUT (Use a vise grips to hold frame in place)
5. Make sure that the front of the OKF grille is flush with the OEM frame. **AND CENTERED.**
6. Remove OKF grille and drill marked holes with a ¼ drill bit.
7. Reinstall OKF grille to the frame. DO NOT OVER TIGHTEN

