

American Cylinder Adapter Part Number 7000ACA

Installation Instructions

1. You will receive the cylinder adapter assembled. Remove the 8-32 machine screw using a 3/32 hex wrench. See Fig. 1. Lay mechanism down horizontally on a flat surface to install the adapter.
2. Place the cam onto the adapter cover in the starting position as in Fig. 2. Insert cover with cam up into mechanism from the flat surface side.
3. Using a flat head screwdriver, rotate cam up into the mechanism to make contact with the spring loaded internal locking parts of the mechanism. See Fig. 3.
4. Guide adapter body into mechanism from the opposite side until it nests with adapter cover. See Fig. 4.
5. Hold together as in Fig. 5 & insert the 8-32 screw through cover side into adapter body as in Fig 6. & tighten.
6. Insert a 5mm cylinder screw into the hole on the mechanism face plate and tighten. Installation is finished.
7. Test. If the mechanism is a multipoint locking mechanism, use a lever and spindle to engage locking points by lifting up on the lever first and then rotating the cylinder adapter with a flat head screwdriver ¼ turn to lock the mechanism. A locked mechanism will not allow the levers to move in a downward fashion.

