

Choose a location that is not subject to direct weather elements. An ideal location is out of direct sunlight, on the North side of a building or in a shady spot. Hang the thermometer from a long nail.