

Modern Mount Vertical Graphics Floor Stand

1. Attach upright to base using screws provided (fig. A, B).
2. Place graphic in the upright channel (fig. C).
3. Fasten graphic into place using headless set screws provided (fig. D).
4. Attach middle upright to graphic (fig. E).
5. Fasten graphic into place using headless set screws provided (fig. F).

NOTE: Model shown below may differ from your model, but assembly instructions remain the same.

