Convex Sign Holder Poster Stand Floorstand (Single Pole)

- 1. Align flathead screws with base and upright holes and screw into place (fig. A).
- 2. Align allen cap screw with upright and wood base holes and screw into place (fig. B).
- 3. To insert graphic, start from wood base. Rest graphic along base contour (fig. C-1).
- 4. Tuck graphic into upright channels as you work your way up the frame (fig. C-2)
- 5. Repeat opposite side.

