



Base Corner Protector with Bump Replacement Instructions (#57, 61, 64, 68)

What's Included:
Base Corner Protector With Bump,
3 screws (plus extras)

Tools Needed:
Phillips head screwdriver



1. Place the trunk upside-down on the floor or on it's side to get started.
2. Remove and discard the three screws from the Base Corner Protector with Bump, currently in place on your footlocker.
3. Position the replacement Base Corner Protector with Bump in the same position as the piece you just removed. Screw in each of the three new screws, tightening halfway. Then go back and fully tighten each screw.

