



# Base (Groove) Corner Clip Replacement Instructions

(#34, 36, 38, 40)

## What's Included:

Base (Groove) Corner Clip

## Tools Needed:

Phillips head screwdriver

Flat head screwdriver

1. Loosen (about halfway, but don't remove) the two screws from the trim bracket currently on your footlocker.
2. Slip off the Base (Groove) Corner Clip currently on your trunk. Position the replacement Base (Groove) Corner Clip in the same position as the piece you just removed and push into place.
3. Rerighten the Trim Bracket.

