



Instruction Guide:

Bug Nets for
Side & Rear Doors



## Gradually remove a section of weatherstripping from its place within door jamb

Around the outer edge of the open doorway, one section at a time, gradually remove the rubber weatherstripping away from the door jamb's pinch seam. During the removal process, do not remove the entire length of the weatherstripping off of the vehicle all at once.

Throughout the installation process, incrementally work your way around the outside of the doorway one section at a time, beginning from the very top of the door arch working your way down the sides, to ensure that your weatherstripping does not become misaligned from its original position.

## Step 2



Slide bugnet outer trim material between weatherstripping and door jamb pinch seam

Once you have a section of weatherstripping removed from the door jamb, from the inside of the vehicle facing outward, slide the outer trim material of the Vanspeed bugnet in between the door jamb pinch seam and the weatherstripping.

By approaching the installation of the bugnet material from the inside facing out, this will prevent the bugnet from becoming stuck and/or damaged during the closure of the door itself. Pushing the material through from the inside will help prevent any unwanted interference.

pictured : side bugnet installation



Close the weatherstripping over the bugnet trim material to lock it into place

Once a section of the bugnet (proportional to the amount of weatherstripping that's been removed) has been inserted into position along the inside of the door jamb, push that section of weatherstripping back into place along the pinch seam, creating a closure between both of the components holding the bugnet into place within the doorway.

After completing this process at the top of the door arch, continue to repeat steps 1-3 until the entire length of the bugnet has been secured within the door jamb.



## You've Reached the Finish Line



