



If you find your casting slip to be too thick, we recommend the following steps:

1. Agitate the slip
2. Mix together $\frac{1}{4}$ cup water and $\frac{1}{8}$ teaspoon of a defloculant (sodium silicate or darvan)
3. Add the defloculant solution to a 2-gallon box of slip and mix well

If you still find that your slip is too thick, repeat the above steps using 1 tsp water to $\frac{1}{8}$ tsp defloculant

**A little deflocculant goes a long way. Be sure not to over-flocculate your slip.

***We do not recommend mixing together Low Fire White talc body slip with Low Fire White non-talc slip