

- 1. Attach 660-501 High Blocks in Groove of Mid Frame (1-each side)
- Attach 660-521 Butterfly Blocks in Groove of Upper Frame (1-each side)
   Place Mid Frame around Upper Frame and slide two 660-500 Low Blocks in Groove of the Upper Frame & fasten to Mid Frame. (2-each side)
- 4. Place Lower Frame around Mid Frame and slide 660-514 Groove Blocks into grooves as shown & fasten toLower Frame.
- 5. Assembly is now complete and can be attached to the Gúdgeon.

						1			
						UNLESS OTHERWISE SPECIFIED:	DATE:	9-25-14	GG Schmitt & Sons
						DIMENSIONS ARE IN INCHES TOLERANCES: FRACTIONAL± 1/64" ANGULAR: MACH±1/2 Deg. BEND ±1 Deg. TWO PLACE DECIMAL ± .03"	DRAWN BY:	Al Bender	GG SCIIIIIII & SOIIS
							APPROVED BY:		Installation Guide
							SCALE:	N/A	
						THREE PLACE DECIMAL ± .015"	GG Schmitt & Sons		for Block Kit
						DO NOT SCALE THIS DRAWING	2821 Old Tree Drive Lancaster, PA 17603 717-394-3701	7230 15th Street East Sarasota, FL 34243 941-360-1967	L08E3105
ed						MATERIAL: Stainless Steel	PROPRIETARY AND CONFIDENTIAL THE INFORMATION CONTAINED IN THIS		B LO8E3105-BLK-I
	-REV-	DATE	REVISION CHANGE NOTES	BY	APPV	FINISH: N/A	DRAWING IS THE SOLE PROPERTY OF GG SCHMITT & SONS. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE		
							WRITTEN PERMISSION OF GG SCHMITT & SON IS PROHIBITED.	OF GG SCHMITT & SONS	ORIG.NO. SAME SHEET 1 OF 1