



Enkadrain® Installation Bulletin

Subsurface Drainage System for Planter Drainage

Read First

These suggestions represent generally accepted procedures for successful installation of Low & Bonar Building Products. These instructions may be followed, modified, or rejected by the owner, engineer, contractor or their representative since they, not Low & Bonar Inc., are responsible for planning and executing procedures appropriate to a specific application.

Preparation

- Ensure planter is clean and free of rocks, soil clods, or other debris that may interfere with drainage system performance.
- Ensure planter bottom has adequate slope that allows proper flow to outlet drain system.
- Check compatibility of adhesive to membrane.

Installation

- Starting at the longest direction of the planter and moving in the opposite direction of the fabric flap, cut the Enkadrain to length and place the fabric flap against the planter bottom.
- Place a bead of construction adhesive 0.125 inches to 0.25 inches (.3cm to .6cm) in a zigzag pattern along the edge of the Enkadrain that will be covered by the fabric overlap. Lay the next strip of Enkadrain. Repeat this until planter bottom is covered.
- Measure the perimeter of the planter. Cut a strip of Enkadrain to the measured length and place horizontally around the planter wall.

Related Documents

Enkadrain Brochure

Data Sheets

- Enkadrain 3611R
- Enkadrain 3615R
- Enkadrain 3811R
- Enkadrain 9120
- Enkadrain 9611 & 9615

Guide Specifications

- Enkadrain Specifications

The data reproduced in this document reflects our best knowledge at the time of issue. It is subject to change arising from new research and development, as are the properties of the products described. We do not accept any liability for results obtained by using this information or the products mentioned. © Low & Bonar bv.