



Note:
After trimming back core & fabric join the two pieces so fabric from each piece touches. Finish by taping joint all the way around with duct tape.

ETD 101B

End to End Splice
Isometric View

Referenced Products

Enkaturf Drain 9320
Enkaturf Drain 9323

Notice

The information provided in this technical detail is presented by way of illustration only and will not apply to every installation. Product application will vary as a result of site conditions, installation procedures and other factors specific to the particular

installation. Colbond Incorporated therefore cannot assume any liability for the manner of installation of its products, which manner of installation is left to the buyer in conjunction with the buyer's architect, engineers, builders or other professionals.

Colbond Inc.

Sand Hill Road
PO Box 1057
Enka, NC 28728
enka-engineered@colbond.com

Tel. (+1) 828 665-5050
Toll Free (+1) 800 365-7391
Fax (+1) 828 665-5009
www.colbond-usa.com