



XERICROSS

162 Shadow Point Dr
St George, UT 84770

Phone: (435) 574-9313

1.75" MOUNTING BRACKET



ITEM	QTY	DESCRIPTION
A	2	1.75 inch clamps
B	2	Adhesive foam strips
C	2	M8 x 16mm flathead mounting bolts
D	1	Mounting plate

MOUNTING INSTRUCTIONS:

Tools: A 5mm hex key will be needed to attach and assemble the mounting bracket

1. Determine a mounting location for the Medical & Emergency Kit. The Kit can be mounted in a variety of locations, and the mounting plate provides multiple holes to mount the plate at various angles and positions. On many UTVs, the crossbar extending behind the passenger compartment provides an ideal location.
2. Slide the first clamp band over roll cage bar and attach the clamp block by threading the clamp bolt into the nut. Do not fully tighten yet.
3. Slide the second clamp band over roll cage bar and position the bands 125mm (4.9") apart. Attach second clamp block, do not tighten.
4. Position the mounting plate on the clamp blocks with the mounting holes (X) positioned over the threaded holes in the clamp blocks. The mounting holes are the six smaller holes toward the center of the plate. The plate may be positioned with either side up. The position of the clamps may need to be adjusted.
5. Insert the flathead mounting bolts through the mounting holes in the plate and tighten.
6. Tighten the clamp mounting bolts.
 - a. If the clamps do not firmly grip the bar when tightened, a section of foam strip may be positioned inside the clamp block or band. It may be sufficient to cut a portion of the strip and adhere it to the inside surface of the clamp block.
7. Center the Kit on the plate and slide the clips over the plate edge. The Kit should slide down on the plate until the plate is seated at the top of the clips.
8. The rivet heads of the clips should sit inside the clearance holes (Y) of the plate.



— PLEASE SEE REVERSE SIDE FOR IMPORTANT INSTRUCTIONS ABOUT MOUNTING ACCESSORY KITS —

— MOUNTING INSTRUCTIONS FOR ACCESSORY BAGS —

The Xericross Medical & Emergency Kit is designed as a modular kit system ready to handle the same high speeds and rugged terrain as your off-road vehicle. The optional accessory bags provide convenient storage for the supplies you use most right on the front of the Kit where you can easily reach them. However, the demanding conditions placed on the bags require a robust attachment mechanism. With this in mind, the accessory bags connect to the primary bag using industrial grade snaps able to hold on through the harshest obstacles. However, these snaps must be properly aligned to correctly engage. Following these instructions will ensure the accessory bags are securely attached.

MOUNTING INSTRUCTIONS FOR ACCESSORY BAGS:

1. Unzip the accessory bag.
2. Unzip the primary kit bag.
3. Place one hand in the primary bag so that your fingers are positioned behind a first snap location on the bag front.
4. Position the accessory bag against the primary bag with an accessory bag snap lined up with the primary bag snap.
 - a. It may be helpful to sight between the bags to make sure the snaps are lined up.
5. Apply pressure to the snap location on the inside of the primary bag at the same time you apply pressure to the snap cover on the inside of the accessory bag. Applying a firm pressure will click the snap portions together.
6. Repeat steps 4 and 5 for the remaining snaps.
 - a. It may be helpful to flex the primary bag slightly if necessary to make sure that the snaps are properly aligned.