



WALL MOUNT ADAPTER BRACKET INSTALLATION INSTRUCTIONS

THE BRACKETS MUST BE MOUNTED INTO A STRUCTURAL MEMBER WITHIN THE WALL (WALL STUD) USING THE LONG SCREWS (B) THAT CAME WITH THE ADAPTER KIT TO ENSURE SAFE OPERATION. ATTACHING WITH THE SHORTER SCREWS (C), OR TO DRYWALL OR PLASTER ONLY IS NOT SUFFICIENT TO SUPPORT THE WEIGHT OF THE CABIDOR AND MAY RESULT IN INJURY.

1. Locate the wall that the Cabidor will be mounted on.
2. Locate a structural member within the wall (wall stud).
3. Using the bracket (A) as a spacer guide for the screws (B), mark and predrill two holes for each bracket (A) ensuring that:
 - A. each bracket (A) is plumb, or vertical. (See Figure 1.2)
 - B. the brackets are no more than 65" apart. (See Figure 1.2)
4. Make sure that the screws are securely anchored into the wall stud.
5. After you have installed your brackets (A), install the vertical bracket bolts (D), lock washers (E), and plastic bushings (F). The vertical bracket bolt (D) and lock washer (E) are inserted up through the threaded bottom of the bracket (A). Slip the plastic bushing (F) over the top of the vertical bracket bolt (D). The Cabidor hanging hardware (G) that came with your cabinet will slip over the exposed top of the vertical bracket bolt (D) and over the plastic bushing (F) in later steps. (See Figure 2)
6. Measure from the top of one vertical bracket bolt (D) to the top of the other vertical bracket bolt (D). Install the hanging hardware on the side of your Cabidor using this dimension so that the spacing between the hanging hardware on the side of the Cabidor matches the spacing of the installed brackets (A). Hanging hardware (G) installation instructions were included with your Cabidor. (See figure 1.2, and Cabidor Installation Instructions)
7. Lift the Cabidor and slip the hanging hardware (G) over each of the vertical bracket bolts (D) and over the plastic bushings (F). Secure the Cabidor hanging hardware (G) with a stop nut (H), placing one stop nut (H) on top of each vertical bracket bolt (D). Tighten each stop nut (H) until it is snug against the top of the plastic bushing (F). (See Figure 2)
8. Finish the installation by following the remainder of the instructions that came with your Cabidor. (See Cabidor Installation Instructions)

