

2008-2014 6.2L Tahoe/Yukon/Escalade Muffler Delete

Professional Installation Recommended

What's Included:

- Delete piece
- 2x 3.5" U-Bolt clamps

Tools Required

- 9/16" wrench
- Preferred cutting tool
- Safety glasses

1. Get underneath the passenger side of the vehicle just forward of the rear tire
2. Use preferred cutting tool to cut your exhaust as close as possible to the front and rear of the muffler



3. Add a clamp to each end of the muffler delete part
4. Slide the delete part onto the stock rear exhaust section
5. Pull down on the factory front exhaust section to allow the new part to slide over the factory exhaust
6. Align tailpipe to desired location
7. Tighten clamps
8. Enjoy the new and improved sound of your ride