

# 2015-2020 5.3L Tahoe, Yukon, Escalade Muffler Delete

Professional Installation Recommended

What's included:

- Muffler delete part
- 2x 2.75" U-Bolt clamps

Tools required

- 9/16" wrench
  - Safety glasses
  - Preferred cutting tool
- Slide under the passenger side of the vehicle just forward of the rear tire
  - Use preferred cutting tool to cut Just After the Flapper Valve (right after the swelled end) Leaving a few inches for The New Pipe To Slip Over



- Make a second cut as close as possible to the rearward most exhaust hanger



- Carefully remove the hangers from their rubber isolators
- Add a clamp to each end of the new delete part
- Insert new hanger into hanger isolator closest to the rear driveshaft
- Slide new delete part over the stock front exhaust section
- Slide original rear exhaust section into the new delete part
- Adjust tailpipe to desired location and tighten clamps
- Enjoy the new and improved sound