

Kit Includes:

Muffler Replacement
Pipe
1 Band Clamp
2 Bolts and Lock Nuts



Tools Needed:

Cutoff Tool
Jack
Wheel Chock
Pliers
13mm Deep Socket
15mm Socket
17mm Socket
5/8 Socket
9/16 Socket

Khaos Motorsports 2019 Ram Muffler Delete Installation Instructions

Thank you for purchasing a muffler delete kit from Khaos Motorsports! Khaos Motorsports will not be at fault for any damages or injuries. Professional installation is recommended.

If you have any questions please send them to sales@khaosmotorsports.com.

Place wheel chocks around tires and engage parking brake. Raise vehicle and place jack stands at secure points. **DO NOT GET UNDER VEHICLE WITHOUT JACKSTANDS IN PLACE!**

1. Measure 1.5" from rear of muffler and mark.
2. Using cutting tool, cut exhaust pipe where marked.
3. Remove the two 13mm nuts that attach the muffler hanger bracket to vehicle.
4. Remove the two 5/8 bolts from the front flange closest to the muffler. Remove ground strap.
5. Now remove muffler from vehicle, along with rubber hangers and hanger bracket.
6. Remove flange gasket, rubber hanger, and hanger bracket from stock muffler.
7. Attach hangers and gasket to Khaos Motorsports Muffler Delete pipe.
8. Place included clamp around expanded end of delete pipe. Do not tighten clamp yet.
9. Slide expanded end onto existing pipe. Using supplied bolts and lock nuts, attach at flange. **DON'T FORGET FLANGE GASKET!**
10. Attach all hangers and ground strap.
11. Check exhaust tips to ensure they are straight.
12. Tighten clamp.
13. Start vehicle, smile, and check for leaks.
14. Remove from jack stands, start truck and do burn outs.

If you have any questions about the installation of this product, check out our YouTube channel for our installation video. Just scan the code with your camera app and it will take you right to it!

