

# 2009-2018 RAM 1500 DUAL EXIT MUFFLER REPLACEMENT

## PROFESSIONAL INSTALLATION RECOMMENDED

(NOTE THESE INSTRUCTIONS ALSO APPLY TO STAINLESS STEEL VERSIONS AS WELL AS ANY VARIATION WITH A STRAIGHT THROUGH OR CHAMBERED STYLE MUFFLER)

### TOOLS REQUIRED

- 15MM WRENCH
- 9/16" WRENCH
- PENETRATING LUBRICANT RECOMMENDED

### WHAT'S INCLUDED

- ONE 3" U-BOLT CLAMP
  - TWO 2.25" U-BOLT CLAMPS
  - MUFFLER DELETE SECTION
1. SLIDE UNDERNEATH THE PASSENGER SIDE OF THE TRUCK
  2. USE 15MM WRENCH TO LOOSEN 1 CLAMP AT THE FRONT OF THE MUFFLER AND 2 CLAMPS AT THE REAR OF THE MUFFLER
  3. SLIP REAR FACTORY EXHAUST SECTION OFF OF THE MUFFLER
  4. SLIDE THE HANGERS OUT OF THEIR RUBBER HANGING LOCATIONS
  5. SLIP MUFFLER OFF OF THE FACTORY EXHAUST
  6. SLIDE NEW DELETE PIECE ONTO THE FORWARD FACTORY EXHAUST
  7. INSERT HANGERS ON NEW DELETE PIECE INTO THEIR RUBBER HANGING LOCATIONS
  8. INSERT REAR EXHAUST SECTIONS INTO THE DELETE SECTION
  9. ADD CLAMPS AND TIGHTEN WITH A 9/16" WRENCH
  10. ENJOY YOUR NEW AND IMPROVED SOUND