

2009-2018 RAM 1500 DUAL EXIT MUFFLER REPLACEMENT

PROFESSIONAL INSTALLATION RECOMMENDED

(NOTE THESE INSTRUCTIONS ALSO APPLY TO STAINLESS STEEL VERSIONS AS WELL AS ANY VARIATION WITH A STRAIGHT THROUGH OR CHAMBERED STYLE MUFFLER)

TOOLS REQUIRED

- 15MM WRENCH
- 9/16" WRENCH
- PENETRATING LUBRICANT RECOMMENDED

WHAT'S INCLUDED

- ONE 3" U-BOLT CLAMP
 - TWO 2.25" U-BOLT CLAMPS
 - MUFFLER DELETE SECTION
1. SLIDE UNDERNEATH THE PASSENGER SIDE OF THE TRUCK
 2. USE 15MM WRENCH TO LOOSEN 1 CLAMP AT THE FRONT OF THE MUFFLER AND 2 CLAMPS AT THE REAR OF THE MUFFLER
 3. SLIP REAR FACTORY EXHAUST SECTION OFF OF THE MUFFLER
 4. SLIDE THE HANGERS OUT OF THEIR RUBBER HANGING LOCATIONS
 5. SLIP MUFFLER OFF OF THE FACTORY EXHAUST
 6. INSERT HANGER AND CLAMP ASSEMBLY INTO THEIR RUBBER HANGING LOCATIONS FROM THE REAR OF THE VEHICLE
 7. SLIDE NEW DELETE PART ONTO THE FRONT SECTION OF YOUR FACTORY EXHAUST
 8. INSERT REAR EXHAUST SECTIONS INTO THE DELETE SECTION
 9. ADD CLAMPS AND TIGHTEN WITH A 9/16" WRENCH
 10. ENJOY YOUR NEW AND IMPROVED SOUND