

# 4<sup>th</sup> Gen RAM Single Exit Muffler Delete

Professional Installation Recommended

## Tools Required:

- 9/16" wrench
- Penetrating lube
- Hanger Plyers

1. Remove clamps holding factory muffler in
2. Slide hangers out of factory hanger locations
3. Slip rear exhaust section out of factory muffler
4. Slip muffler off front section of exhaust
5. Slide the new hanger and clamp assembly into the factory hanger locations, be sure to slide the hangers in from the rear of the vehicle
6. Slip the new delete piece onto the factory exhaust sections
7. Add the nut side of the clamps onto the u bolt section and add the nuts to hold them on
8. Adjust tailpipe to desired location and tighten all clamps