

# HELLCAT THROTTLE BODY TO 5.7/6.1 INTAKE INSTALL INSTRUCTIONS

## TOOLS NEEDED:

- FLATHEAD SCREWDRIVER
- 5/16 WRENCH
- 5MM ALLEN WRENCH



1. OPEN HOOD
2. CAREFULLY REMOVE ENGINE COVER
3. LOOSEN HOSE CLAMPS ON INTAKE TUBE
4. UNPLUG MASS AIRFLOW SENSOR
5. REMOVE INTAKE TUBE
6. UNPLUG THROTTLEBODY
7. USE 5/16 WRENCH TO REMOVE 4 BOLTS HOLDING THROTTLEBODY TO INTAKE
8. INSTALL PROVIDED O-RING INTO RECEIVER GROVE IN ADAPTER
9. USE PROVIDED (COARSE THREAD FOR PLASTIC INTAKE) (FINE THREAD FOR METAL INTAKE) HARDWARE TO BOLT ADAPTER TO INTAKE MANIFOLD (O-RING OUT).
10. USE LONG FINE THREAD HARDWARE TO BOLT HELLCAT THROTTLEBODY TO ADAPTER
11. PLUG IN THROTTLEBODY
12. PLUG IN MASS AIRFLOW SENSOR
13. TIGHTEN INTAKE TUBE HOSE CLAMPS
14. REPLACE ENGINE COVER
15. CLOSE HOOD AND ENJOY!