

PROFESSIONAL INSTALL RECOMMENDED

Dodge Mopar 6.4L OIL CATCH CAN INSTALL INSTRUCTIONS

TOOLS NEEDED:

- 6MM ALLEN WRENCH
- 2.5MM ALLEN WRENCH



1. OPEN HOOD
2. CAREFULLY REMOVE PASSENGER SIDE ENGINE COVER
3. CAREFULLY REMOVE WIRING HARNESS FROM FRONT OF HEAD
4. USE SUPPLIED BUTTON HEAD HARDWARE TO INSTALL MOUNTING RING TO MOUNTING BRACKET
5. USE SHORTER OF THE LARGER HARDWARE TO BOLT THE MOUNTING BRACKET TO THE FRONT OF THE HEAD (LOWER HOLE)
6. USE THE LARGER BOLT TO SECURE THE TOP OF THE MOUNTING BRACKET TO THE HEAD
7. REINSTALL WIRING HARNESS INTO HOLES ON BRACKET
8. USE BUTTON HEAD HARDWARE TO ATTACH CAN TO MOUNTING RING (DO NOT FULLY TIGHTEN)
9. REMOVE CRANK CASE VENT HOSE
10. INSTALL LONGER HOSE FROM REAR PART TO INLET PORT ON CAN
11. REMOVE 90 DEGREE BOOT FROM FACTORY PIPE
12. INSTALL DOUBLE ENDED BARBED FITTING INTO 90 DEGREE BOOT
13. INSTALL BOOT ONTO ORIGINAL MOUNT LOCATION
14. INSTALL HOSE FROM 90 DEGREE BOOT TO OUTLET SIDE OF CAN
15. FULLY TIGHTEN BOLTS ON TOP OF CAN
16. REPLACE ENGINE COVER AND YOU'RE ALL DONE!!