

# BASE CHALLENGER HOOD BEZEL

## PROFESSIONAL INSTALLATION RECOMMENDED

### TOOLS REQUIRED

- TRIM REMOVAL TOOL

1. OPEN HOOD
2. USE TRIM REMOVAL TOOL TO REMOVE 9 PLASTIC PUSH CLIPS HOLDING THE INSULATION TO THE UNDERSIDE OF THE HOOD
3. REMOVE UNDERHOOD INSULATION
4. DEPRESS RETAINING CLIPS TO RELEASE VENT
5. PULL VENTS OUT THE TOP OF THE HOOD
6. PUT NEW VENTS INTO PLACE AND PRESS DOWN TO SNAP INTO PLACE
7. REINSTALL UNDERHOOD INSULATION
8. CLOSE HOOD AND ENJOY THE NEW LOOK