

# CHEVY 1500 RESONATOR DELETE

PROFESSIONAL INSTALLTION RECOMMENDED

## TOOLS NEEDED

- PREFERED CUTTING METHOD
- 9/16 WRENCH
- TAPE MEASURE
- PERMENANT MARKER

## WHAT'S INCLUDED

DELETE PIPE  
1-2.75" U-BOLT CLAMP

1. MEASURE AND MARK 9.5" REARWARD OF HANGER
2. USE PREFERED CUTING METHODTO CUT ON MARK
3. SLIDE HANGER OUT OF RUBBER GROMIT
4. RE INSERT NEW HANGER INTO RUBBER GROMMIT
5. SLIDE NEW PART ONTO PRE-EXISTING EXHAUST
6. PUT CLAMP OVER JOINT AND TIGHTEN