

## CHARGER 3.6 V6 SINGLE MUFFLER DELETE KIT INSTRUCTIONS

1. Raise car up
2. Remove 4 13mm nuts, holding rear most crossmember in
3. Use Tape measure and permanent marker to mark 1 inch rearward of muffler
4. Use tape measure and permanent marker to mark 9.75 inches forward of muffler
5. Use preferred method of cutting to cut on those marks
6. Remove 4 13mm bolts holding hangers to car
7. Remove Rear exhaust section
8. Slide long side of delete onto factory exhaust (towards front of car)
9. Reinstall rear exhaust section
10. Install clamps onto delete and tighten
11. Lower car and enjoy the new sound!

