

Dodge Mopar 6.4 INTAKE TO HELLCAT 6.2 THROTTLEBODY

TOOLS NEEDED:

- **FLAT HEAD SCREWDRIVER**
- **5/16 WRENCH**
- **5MM ALLEN WRENCH**



1. LOOSEN INTAKE TUBE HOSE CLAMPS WITH FLATHEAD SCREWDRIVER
2. UNPLUG MASS AIRFLOW SENSOR
3. REMOVE INTAKE TUBE
4. USE 5/16 WRENCH TO REMOVE FOUR BOLTS HOLDING THROTTLE BODY TO INTAKE
5. UNPLUG THROTTLEBODY
6. INSTALL PROVIDED O-RING INTO RECEIVER GROVE IN ADAPTOR
7. USE PROVIDED HEX HARDWARE TO BOLT ADAPTOR O-RING SIDE OUT TO INTAKE MANIFOLD
8. USE PROVIDED ALLEN HEAD HARDWARE TO BOLT HELLCAT THROTTLE BODY TO ADAPTOR
9. PLUG IN THROTTLEBODY
10. REINSTALL INTAKE TUBE AND PLUG IN MASS AIR FLOW SENSOR

11. TIGHTEN HOSE CLAMPS
12. CLOSE HOOD AND ENJOY!!!!

PROFESSIONAL INSTALLATION RECOMMENDED