

# JEEP JL WRANGLER MUFFLER DELETE

## PROFESSIONAL INSTALLATION RECOMMENDED

### TOOLS REQUIRED

- 15MM WRENCH

### PIECES INCLUDED

- DELETE SECTION
- ONE 2.5" U-BOLT CLAMP

1. SLIDE UNDER THE REAR OF THE VEHICLE
2. LOOSEN THE 15MM NUT OF THE FACTORY EXHAUST CLAMP ABOVE THE REAR AXLE
3. PULL HANGERS OUT OF THEIR HANGING LOCATION
4. SLIP MUFFLER SECTION OUT OF FACTORY EXHAUST
5. INSERT HANGER ON DELETE PIECE INTO FACTORY HANGING LOCATION
6. SLIDE CLAMP ONTO DELETE PEICE
7. SLIP NEW DELETE SECTION OVER STOCK EXHAUST
8. ADJUST EXHAUST UNTILL DESIRED FIT IS ACHIVED AND TIGHTEN CLAMP
9. ENJOY YOUR NEW SOUND