

# SRT/HELLCAT OVAL MUFFLER DELETE



## Tools Needed:

- Safety Glasses
- Gloves
- 13 MM Wrench
- Tape Measure
- Jack and Jack stands
- Permanent Marker
- 9/16" Wrench
- Sawzall or Other Method Of Cutting Tool

## Instructions

### Professional install Recommended

- JACK UP CAR AND PLACE JACKSTANDS UNDER CAR FOR SAFETY
- SLIDE UNDER THE CAR (FORWARD) AND MEASURE 1.75" FROM THE WELD ON THE MUFFLER AND MARK ON THE OUTER SIDE OF EACH PIPE.
- MEASURE AND MARK 1.125" OR 1 AND 1/8" FORWARD OF THE WELD ON THE MUFFLER ON THE INSIDE OF THE PIPES AND MAKE A STRAIGHT LINE BETWEEN MARKS ON EACH PIPE.
- MEASURE AND MARK .375" OR 3/8" REARWARD OF THE WELD ON THE MUFFLERS INSIDE AND OUT OF THE PIPE AND MAKE A STRAIGHT LINE BETWEEN MARKS
- USE PREFERRED CUTTING DEVICE TO CUT MUFFLERS OUT (USE LINES AS GUIDE TO MAKE STRAIGHT CUTS
- ONCE MUFFLERS ARE CUT OUT USE 13MM WRENCH TO UNBOLT ALL EXHAUST HANGERS WHILE MAKING SURE TO SUPPORT REAR EXHAUST SECTION BEFORE REMOVING HANGERS
- SLIDE SUPPLIED CLAMPS ON DELETE PIPE THEN SLIDE THE DELETE PIPES ON SHORT END TOWARDS X-PIPE
- SLIDE REAR EXHAUST INTO LONG END OF DELETE PIPES AND BOLT ALL HANGERS BACK INTO PLACE
- SLIDE CLAMPS OVER EXPANDED END OF DELETE PIPE AND TIGHTEN DOWN
- NOW YOU'RE READY TO GET YOUR CAR OFF THE JACK STANDS AND ENJOY THE NEW SOUND OF YOUR HEMI.

**Hold Delete tube part up to  
mark measurements and verify before cutting!!!**

