

GM TBI Spacer Installation Instructions

Professional Installation Recommended

Tools required:

1/2" wrench

Razor blade/gasket scraper

1. Open hood
2. Remove air cleaner
3. Remove three bolts holding tbi unit to the intake manifold
4. Clean all the old gasket material off the intake and tbi unit
5. Place one new gasket on the intake manifold
6. Place the spacer on top of the new gasket and add the second new gasket on top of the spacer
7. Place the tbi unit on top of the spacer and gasket stack and add the supplied bolts
8. Evenly tighten all the bolts to ensure a good seal
9. Reinstall the air cleaner
10. Close hood and enjoy