



Steeda S550 Front Lower Control Arms

Installation Instructions for Part: 555-4905, 555-4906, and 555-4907



Tools Required

- 1/2" drive ratchet
- 21 mm socket
- 24 mm socket
- Hammer

Removal Instructions

1. Support the car on a lift or jack stands.
2. Remove the front wheels.
3. Remove both of the front lower control arms, indicated in Figures 1 and 2.

NOTE: Be careful not to damage the threads.



Figure 1: Factory lateral link



Figure 2: Factory tension link

Installation Instructions

1. Install the Steeda front lower control arms.
NOTE: Reuse the factory nuts and bolts.
2. Torque to the following specs:

Front Lower Control Arm to Subframe (Inboard): 185 ft/lbs

Front Lower Control Arm to Spindle (Outboard): 85 ft/lbs

NOTE: An alignment is suggested after installing this part.