













2015-2017 (S550) Mustang Springs

Spring	Fitment	Application	Spring Rate (lb/in)		Drop (in)		Compatibility		Recommendations	Notes
			Front	Rear	Front	Rear	Factory shocks & struts	Pro-Action shocks & struts		
	Sport (Linear) 555-8208	GT/V6 (Coupe & Convertible)	Street/Track	200	800	1	1	✓	✓	Best paired with non-adj Pro-Action Upgraded swaybars recommended
	Sport (Linear) 555-8209	Ecoboost (Coupe & Convertible)	Street/Track	200	800	1	1	✓	✓	Best paired with non-adj Pro-Action Upgraded swaybars recommended
	Sport (Progressive) 555-8210	GT/V6 (Coupe & Convertible)	Street/Track	145 - 225	525 - 820	1.125	1	✓	✓	Best paired with non-adj Pro-Action Upgraded swaybars recommended
	Sport (Progressive) 555-8212	Ecoboost (Coupe & Convertible)	Street/Track	145 - 225	525 - 820	1.125	1	✓	✓	Best paired with non-adj Pro-Action Upgraded swaybars recommended
	Ultralite (Linear) 555-8211	GT/V6 (Coupe & Convertible)	Street	200	800	1.125	1	✓	✓	Best paired with adj Pro-Action Upgraded swaybars recommended
	Ultralite (Linear) 555-8213	Ecoboost (Coupe & Convertible)	Street	200	800	1.125	1	✓	✓	Best paired with adj Pro-Action Upgraded swaybars recommended
	Ultralite Extreme (Linear) 555-8214	GT/V6 (Coupe & Convertible)	Street	225	800	2	2	✓	✓	Best paired with adj Pro-Action Camber plates required
	Ultralite Extreme (Linear) 555-8222	Ecoboost (Coupe & Convertible)	Street	225	800	2	2	✓	✓	Best paired with adj Pro-Action Camber plates required
	Competition (Dual Rate) 555-8246	ALL (Coupe & Convertible)	AutoX/Track	220 - 350	800 - 1200	0.75	0.75	✓	✓	Best paired with adj Pro-Action Upgraded swaybars necessary
	Adjustable Rear (Progressive) 555-8171	ALL (Coupe & Convertible)	Street/Track	N/A	850 - 1000	N/A	0.75 - 1.5	✓	✓	Best paired with adj Pro-Action Upgraded swaybars necessary
Drag Race (Coming Soon)	GT (Coupe & Convertible)	Street/Track	150	800	0.625	0.625	✓	✓	Best paired with adj or non-adj Pro-Action No front swaybar, Drag rear swaybar recommended	
Minimum Drop (Coming Soon)	GT/Ecoboost (Coupe & Convertible)	Street	200	750	0.5	0.5	✓	✓	Best paired with non-adj Pro-Action	