



FITTING INSTRUCTIONS FOR CR0021BK COTTON REELS WITH ADJUSTER BLOCKS YAMAHA R6 '06-



Please note that the way the kit is packed does not necessarily represent the way of mounting to the bike

Please read all instructions before commencing fitting

- Raise rear of bike on original stand bobbin mounts (use paddock stand bobbins in OEM mounting holes), support rear wheel (suggest using blocks of wood) to prevent wheel from dropping when rear spindle is removed.
- Undo the rear spindle nut.
- Remove the rear spindle and remove the original adjuster blocks.
- Remove the adjuster bolts from the rear of both of the original adjusters and refit to the R&G adjuster blocks using the two flanged nuts supplied in the kit.
- Place the new adjuster blocks over the end of the swing arm. The one with a slot goes on the LHS of the bike so flats of spindle head sit into slot .
- Slide spindle through the swing arm, brake calliper and rear wheel.
- Refit the spindle nut and tighten according to the manufacturer's instructions and check chain adjustment.
- Remove bike from the paddock stand, and remove the paddock stand bobbins and bolts from OEM paddock stand mounts.
- Fit the new cotton reels to the new adjuster blocks on both sides as shown above.

CONSUMER NOTICE

The catalogue description and any exhibition of samples are only broad indications of the Products and R&G may make design changes which do not diminish their performance or visual appeal and supplying them in such state shall conform to the order. The Buyer acknowledges no representation or warranty (other than as to title) has been given or will apply to the Products other than those in R&G's order or confirmation and the Buyer confirms it has chosen the Products as being of merchantable quality and suitable for its particular purposes. Where R&G fits the Products or undertakes other services it shall exercise reasonable skill and care and rectify any fault free of charge unless the workmanship has been disturbed. The Buyer is responsible for ensuring that the warranty on the motorcycle is not affected by the fitting of the Products. On return of any defective Products R&G shall at its option either supply a replacement or refund the purchase money but shall not be liable if the Products have been modified or used or maintained otherwise than in accordance with R&G's or manufacturer's instructions and good engineering practice or if the defect arises from accident or neglect. Other than identified above and subject to R&G not limiting its liability for causing death and personal injury, it shall not be liable for indirect or consequential loss and otherwise its liability shall be limited to the amounts paid by the Buyer for the Products or the fitting or service concerned. These terms do not affect the Buyer's statutory rights.

R&G RACING RETURNS POLICY (NON-FAULTY GOODS)

Returns must be pre-authorized (if not pre-authorized the return will be rejected). Goods may only be returned direct to us if they were purchased direct from us (customer must prove if necessary). Otherwise to be returned to original vendor. Goods must be in resellable condition, in the opinion of R&G Racing. All returns are subject to a 25% restocking and handling fee (25% of the gross value exc. P&P – at the prevailing price at time of purchase). The customer must pay any and all carriage charges. No returns of



discontinued products, unless within 14 days of purchase. This policy does not affect your statutory rights and does not refer to faulty goods.

FRANCE
INSTRUCTIONS DE MONTAGE DE CR0021BK
YAMAHA R6 '06-

LA PRESENTATION DES PIECES R&G DANS L'EMBALLAGE N'EST PAS TOUJOURS IDENTIQUE AU SENS DE MONTAGE.

Merci de noter que dans le cas où les protections sont assemblées avec une bague en caoutchouc, merci de bien vouloir le retirer lors du montage des pièces sur la moto.

Merci de lire la notice de montage avant de commencer le montage de la pièce.

- Prendre les diabolos R&G et les monter à l'aide des vis fournies sur le bras oscillant à l'endroit des filetages et lever la moto à l'aide d'une béquille de stand.
- Lever l'arrière de la moto, de manière à ne plus mettre la roue arrière en contact avec le sol.
- Mettre une cale sous le pneu arrière, de manière à laisser la roue en position lors du démontage de l'axe arrière
- Enlever l'écrou d'axe de roue arrière.
- Enlever l'axe de roue.
- Enlever les tendeurs de chaîne d'origine
- Enlever les vis de réglage des tendeurs de chaîne d'origine et les remonter sur les tendeurs R&G.(utiliser les deux écrous dorés livrés dans le kit).
- Placer les blocs R&G sur le bras oscillant de la moto, le modèle ayant une rainure sera à placer sur le côté Gauche
- Glisser l'axe d'origine sur la moto, à travers le bras oscillant, la patte de montage de la pince de frein arrière et à travers la roue arrière.
- Remonter l'écrou d'origine sur l'axe
- Faire le réglage de tension de chaîne, puis serrer l'écrou de l'axe au couple de serrage d'origine.
- Ouvrir la béquille latérale de la moto.
- Puis enlever la béquille de stand.
- Enlever les diabolos du bras oscillant et les remonter sur les prolongateurs R&G.