

NEW RAGE CYCLES

INSTALLATION INSTRUCTIONS

SUZUKI GSXR 600/750

MIRROR BLOCK OFF TURN SIGNALS 2011-2017

- 1 Remove (6) phillips head screws, (3) on either side, and remove windshield (picture 1)
- 2 With 4mm allen key, remove bolt below dash (picture 2)
- 3 Pop dash off to expose OEM connectors. Unplug dash to make it easier for yourself (picture 3)
- 4 Remove (2) 10mm nuts to remove stock mirrors (picture 4)
- 5 Take NRC block off signals and run connector through center hole on fairing (picture 5)
- 6 Run wires through fairing and into dash panel and plug into OEM connectors (picture 6)
- 7 Slide M5x35 bolts through signals, use supplied nuts and washer plate to sandwich together (picture 7)
- 8 Reinstall windshield
- 9 Plug dash in and reinstall bolt

