## INSTALLATION INSTRUCTIONS

## TRIUMPH STREET TRIPLE

## FRONT SIGNAL

- 1 Unbolt stock turn signals from bike (picture 1)
- 2 Unscrew plastic lens and unplug, sliding harness completely out (picture 2/3)
- Unscrew top plate and lens from NRC turn signal, and bolt onto bike using stock bolt (picture 4)
- Plug NRC wires into stock harness, and shrink tube the connections (picture 5)
- Line up lens and screw in top plate, zip tying the wires behind the fairing (picture 6)











