



1.

- **PACKING LIST:**
- **1X LINKPIPE**
- **2X CLAMPS**
- **1X SILENCER OF CHOICE AND STRAP**
- **1X MOUNTING BRACKET FOR PANNIER USE (OPTIONAL)**
- **1X CARBON GASKET**
- **1X M8 X 20MM CAP SCREW**
- **1X NYLOC NUT**
- **2X M8 WASHERS**

2.

- **Fitting Instructions**

- **We advise that this product is fitted by an experienced motorcycle mechanic.**
- **Please check packing list before you start.**
- **Secure motorcycle on level ground using a paddock stand. Recommended!**
- **Remove seat and R/H side panel.**
- **Disconnect exhaust valve cable.**



- **Remove standard silencer.**
- **Clean collector pipe of old gasket material, dirt and carbon deposits.**

3.

- **Insert carbon gasket on to the down pipe outlet.**
- **Fit clamp to the link pipe and insert the pipe on to the collector.**



- **Fit the optional drop bracket on to the footrest hanger.**
- **Fit silencer with clamp on to the link pipe and fit the strap around the silencer and to the bracket.**



4.

- **Check pannier clearance.**



- **Starting from the front, working rearwards tighten all clamps and fasteners.**

- **Start the engine and check for leaks.**
- **After your first ride out, check all fasteners for tightness, especially the baffle bolt.**