

# NEW RAGE CYCLES

## INSTALLATION INSTRUCTIONS

### 2017 YAMAHA R6

#### MIRROR BLOCK OFF PLATES

- 1 Remove (2) 10mm nuts, unplug connector, and take mirrors off (picture 1)
- 2 Put block off plates on fairing, slide provided M5 bolts through and tighten nuts (pictures 2/3/4)

