





- ② Install the accessories on the truck and tighten the screws.
- 3 Installation complete.



