



Outdoor Applications of Mighty Line Tape

For outdoor applications of Mighty Line tape we recommend using a concrete sealer like [V-seal 101](#).

Application process:

1. Clean concrete to which tape is to be applied; power wash with Simple Green or another mild detergent.
2. Rinse.
3. The [101 sealer](#) is a water soluble penetrating sealer. Before applying the sealer, the concrete can be damp but should not have any puddles on it.
4. Apply the sealer with a standard garden sprayer. Put a light mist over the area. Let the area dry an hour or so depending on climate and conditions. Apply another light coating. Let dry.
5. We suggest sealing the whole area that is to be striped, but you could seal a 2 foot path where the Mighty Line is to be applied.
6. Think of concrete as a big sponge. Concrete takes on water every time it gets wet. The V-seal keeps water from penetrating (and at the same time, allows the concrete to breathe) thus keeping the adhesive on the underside of the Mighty Line from absorbing moisture.
7. If you notice a small white/gray residue on the concrete, the sealer has been applied a little thick in that area, do not worry it will wear off with time or you can spray it off with a pressure sprayer.
8. After the sealer and the concrete are dry, you can apply the Mighty Line floor tape.
9. Mighty Line will adhere better and the sealer will dry quicker on warm sunny days.
10. At any deep cracks, saw joints or groove marks, we suggest cutting the Mighty Line.
11. If you leave a space for water to affect the tape the tape will likely breakdown in that area.
12. Spray V-Seal on top of the Mighty Line Floor Tape edges after the tape is down to encapsulate the adhesive from moisture seepage.

Thanks for using Mighty Line Tape!