

SCREW-ON HOLD

INSTALLATION OVERVIEW



NEVER OVER-TIGHTEN



INSPECT HOLDS FOR
CRACKS AND / OR ANY
STRUCTURAL DEFECTS
PRIOR TO INSTALLATION



ENSURE THREADED PART
OF THE SCREW IS FULLY
IN THE PLYWOOD
(MIN. 3/4" PLYWOOD)



NON-STRUCTURAL SCREWS

NOT RECOMMENDED FOR
CLIMBING WALLS OR HOLDS



STRUCTURAL SCREWS

USE #9 OR #10 SCREWS FOR
INSTALLATION OF OUR PRODUCTS



ENSURE ALL PROVIDED
ATTACHMENT POINTS ARE USED

