


REN*STUDIO

PAX | COVER PANEL INSTALLATION

CONTENTS_ 28mm Screws



REQUIRED_ Electric screwdriver, fine gauge drill bit

SIDE PANEL INSTALLATION_

1 Position. Note that the cover panel is deeper than the cabinet frame so that the front edge sits 'flush' with the door face. We suggest a clamp bar or extra pair of hands to hold the panel in place while fixing.

2 Attach. Use the 28mm screws provided to screw from inside the cabinet through to the cover panel. 8 evenly spaced screws (4 front & 4 back) are sufficient for both 201cm and 236cm high Pax frames.

TIP_

Pre-drilling the cabinet interior with shallow pilot holes will make the attachment process easier. Always ensure the pilot hole size is less than the thickness of the screw.

SAFETY_

Please note that fronts and cover panels add significant additional weight to your cabinet. The wall anchor attachments provided with your IKEA cabinet **must be installed** in every instance, even on low height cabinets.

Ren Studio recommends professional installation by a qualified tradesperson, and will not be held responsible for any property damage or injury caused by inadequate fixing of cabinets to walls.

