

# KD2 Headboard & Footboard Bracket Installation Instructions

## Recommended Tools

- socket wrench
- crescent wrench

## Included



Nut  
(x8)



Long Bolt  
(x8)



Side Bracket 1  
(x2)



Washer  
(x8)



Short Bolt  
(x8)



Side Bracket 2  
(x2)



T-Connector  
(x4)

- 1 Carefully place the base flat or in a side clamshell position (see figure 1a & 1b.) *Two people are recommended for this step.*



Figure 1a.



Figure 1b.

- 2 **Hardware: (x2) Long Bolts, (x2) Nuts, (x2) Washers, (x1) Side bracket**  
Locate the two holes on the frame at the corner of the adjustable base, by the leg. Find the side bracket with the correct angle (see figure 2a). Align bracket with base holes and attach using (x2) Long Bolts, (x2) Nuts and (x2) Washers (see figure 2b). Repeat this step for all sides

Figure 2a.



Figure 2b.



- 3 **Hardware: (x2) Short Bolts, (x2) Nuts, (x2) Washers, (x2) T-connector's**  
Carefully place the base near its desired location. Attach each T-Connector with (x2) Short Bolts, (x2) Nuts and (x2) Washers. Find the correct height and width for the headboards/footboards and attach using the extra bolts or the bolts provided with your existing furniture. Check that all brackets and furniture are secured prior to use.

