







SBKDG Headboard & Footboard Bracket Installation Instructions

Recommended Tools	Included
<ul style="list-style-type: none">• 1/2 in. Wrench• 14mm Socket Wrench	 <p>Nut (X8)</p>  <p>Washer (X8)</p>  <p>Long Bolt (X8)</p>  <p>Short Bolt (X8)</p>  <p>Underneath Bracket (X4)</p>  <p>T-Connector (X4)</p>

- 1** Carefully place the base flat or in a side clamshell position (see figure 1a & 1b.)
Two people are recommended for this step.



Figure 1a.



Figure 1b.

- 2** **Hardware: (x2) Long Bolts, (x2) Nuts, (x2) Washers, (x1) Underneath bracket**
Locate the two holes on the frame underneath the base. Position the (x1) Underneath Bracket as far as it needs to be from the headboard/footboard. Align bracket with base holes and attach using (x2) Long Bolts, (x2) Nuts and (x2) Washers. Repeat this step for all sides needed.



- 3** **Hardware: (x2) Short Bolts, (x2) Nuts, (x2) Washers, (x2) T-connector's**
Carefully place the base near its desired location. Attach each T-Connector with (x2) Short Bolts, (x2) Nuts and (x2) Washers. Find the correct height and width for the headboards/footboards and attach using the extra bolts or the bolts provided with your existing furniture. Check that all brackets and furniture are secured prior to use.

