

LONE WOLF CUSTOM GEAR

D'ACQUISTO SERIES DOUBLE STEP STICK ASSEMBLY INSTRUCTIONS

Tools Needed

5/16 open end wrench

3/8 open end wrench

9/16 open end wrench



Kit Contains (per one stick)

(1) Cam Strap

(4) 3/8 x 16 x 3" Square Head studs

(4) 3/8 x 16 nuts



Step 1. Sub assemble all nuts onto bolts. Approximately 1inch (use button head shaft or tape measure for reference)

Step 2. Carefully start to screw the stud into hole on the back side of stick *be sure not to cross thread* You should be able to get at least 1 to 2 turns without using a wrench If needed use 3/8 open wrench.

Step 3. Run all 4 studs into stick until screw ends are flush with the stick surface

Step 4. Thread the top two studs an additional 3 full turns. You should end up with the top two screws sticking out of the stick. (this is for stick alignment when stacking)

Step 5. Tighten the nut using the 9/16 open end wrench and 3/8 wrench to secure the square end of the stud.

Step 6. Hand start the Micro versa button into the provided hole. Tighten with 5/16 wrench until the button sits flush on the stick.

Step 1. Sub assemble all nuts onto bolts. Approximately 1inch (use button head shaft or tape measure for reference)



Step 2. Carefully start to screw the stud into hole on the back side of stick *be sure not to cross thread* You should be able to get at least 1 to 2 turns without using a wrench If needed use 3/8 open wrench.

Step 3. Run all 4 studs into stick until screw ends are flush with the stick surface

Step 4. Thread the top two studs an additional 3 full turns. You should end up with the top two screws sticking out of the stick. (this is for stick alignment when stacking)

Step 5. Tighten the nut using the 9/16 open end wrench and 3/8 wrench to secure the square end of the stud.

Step 6. Hand start the Micro versa button into the provided hole. Tighten with 5/16 wrench until the button sits flush on the stick.

note*- Be sure the FLAT end of stud is to the top and flush with step as shown

