

## 4" LED RECESSED DOWNLIGHT INSTALLATION INSTRUCTIONS

### NOTE:

- Read carefully before installing fixture. Retain these instructions for future reference.
- All electrical connections must be in accordance with local and national electrical code (N.E.C) standards. If you are unfamiliar with proper electrical wiring connections, obtain the services of a qualified electrician.

### IMPORTANT:

- Before performing installation or maintenance, turn off the power supply at the circuit breaker or fuse box.
- Do not make or alter any open holes in the enclosure to the wiring or electrical components during kit installation.
- To prevent wiring damage or abrasion, do not expose wiring to edges of sheet metal or other sharp objects.
- Suitable for wet locations.
- Suitable for Type IC as well as Type NON-IC.
- Use only in open luminaires.
- This product is not intended for use with emergency exits.

### INSTALLATION INSTRUCTIONS:

- Thread the SOCKET ADAPTER into the SOCKET. (FIG. 3)
- Plug the FEMALE CONNECTOR of the RETROFIT TRIM onto the MALE CONNECTOR of the HALO HOUSING. (FIG. 4)
- Tuck all wires into the CAN and carefully push the RETROFIT TRIM into CAN. (NOTE: To provide enough room in shallow cans, carefully position SOCKET ADAPTER and SOCKET adjacent to the long side of the LED DRIVER prior to inserting the RETROFIT TRIM into the CAN.) (FIG. 5)

