

NOTE: USE 2 INCH LONG (OR LONGER) WOOD SCREWS FOR MOUNTING