

## APPLICATION LIST - NINJA LASER

MAKE	MODEL	START YEAR	END YEAR	CLAMP	ADAPTOR
Acura	CSX	2006	2011	AC	
Acura	ILX	2013	2020	AC	
Acura	MDX	2007	2020	AC	
Acura	NSX	2017	2020	AC	
Acura	RDX	2007	2020	AC	
Acura	RL	2005	2012	AC	
Acura	RLX	2014	2017	AC	
Acura	TL	2007	2014	AC	
Acura	ZDX	2010	2013	AC	
Alpha Romeo	147	2000	2010	AC	
Audi	A1	2010	2020	AC	
Audi	A2	1999	2005	AC	
Audi	A3	1996	2013	AC	
Audi	A4	1996	2013	AC	
Audi	A4 Avant	2004	2010	AC	
Audi	A5	2008	2020	AC	
Audi	A6	1996	2020	AC	
Audi	A6 Avant	2004	2010	AC	
Audi	A7	2012	2013	AC	
Audi	A8	1996	2013	AC	
Audi	Allroad	2013	2013	AC	
Audi	Allroad Quattro	1996	2012	AC	
Audi	Q5	2008	2020	AC	
Audi	Q7	2006	2020	AC	
Audi	R8	2008	2013	AC	
Audi	RS6	2004	2008	AC	
Audi	S3	1999	2003	AC	
Audi	S4	1996	2013	AC	
Audi	S4 Avant	2004	2007	AC	
Audi	S5	2007	2020	AC	

## APPLICATION LIST - NINJA LASER

MAKE	MODEL	START YEAR	END YEAR	CLAMP	ADAPTOR
Audi	S6	1999	2020	AC	
Audi	S8	1996	2010	AC	
Audi	TT	1996	2020	AC	
Bajaj	Pulsar	2020	2020	AC	
BMW	3 Series	1990	1998	AC	
BMW	5 Series	1988	2002	AC	
BMW	7 Series	1987	2002	AC	
BMW	8 Series	1987	1995	AC	
BMW	M3	1990	1992	AC	
BMW	M5	1988	1992	AC	
BMW	Z3	1990	1997	AC	
Buick	Allure (Canada Only)	2010	2014	AC	
Buick	Cascada	2016	2019	AC	
Buick	Enclave	2018	2020	AC	
Buick	Encore	2013	2020	AC	
Buick	Envision	2017	2020	AC	
Buick	LaCrosse	2010	2019	AC	
Buick	Regal	2011	2020	AC	
Buick	Verano	2012	2017	AC	
Cadillac	ATS	2013	2014	AC	
Cadillac	ATS	2015	2019	AC	
Cadillac	CT4	2020	2020	AC	
Cadillac	CT5	2020	2020	AC	
Cadillac	CT6	2017	2020	AC	
Cadillac	CTS	2014	2019	AC	
Cadillac	ELR	2014	2017	AC	
Cadillac	Escalade	2015	2020	AC	
Cadillac	SRX	2010	2014	AC	
Cadillac	SRX	2015	2017	AC	
Cadillac	XT4	2019	2020	AC	

## APPLICATION LIST - NINJA LASER

MAKE	MODEL	START YEAR	END YEAR	CLAMP	ADAPTOR
Cadillac	XT5	2017	2020	AC	
Cadillac	XT6	2020	2020	AC	
Cadillac	XTS	2010	2014	AC	
Cadillac	XTS	2015	2019	AC	
Chevrolet	5500 Chassis Cab	2020	2020	AC	
Chevrolet	Blazer	2019	2020	AC	
Chevrolet	Bolt	2017	2020	AC	
Chevrolet	Camaro	2010	2020	AC	
Chevrolet	Caprice PPV	2011	2013	AC	
Chevrolet	Caprice PPV	2014	2014	AC	
Chevrolet	Colorado	2015	2020	AC	
Chevrolet	Corvette	2014	2020	AC	
Chevrolet	Cruze	2011	2020	AC	
Chevrolet	Equinox	2010	2020	AC	
Chevrolet	Express	2015	2020	AC	
Chevrolet	Impala	2014	2020	AC	
Chevrolet	Malibu	2014	2020	AC	
Chevrolet	Orlando (Canada Only)	2011	2014	AC	
Chevrolet	Silverado	2014	2020	AC	
Chevrolet	Silverado 1500	2019	2020	AC	
Chevrolet	Silverado 2500/3500	2015	2019	AC	
Chevrolet	Sonic	2011	2020	AC	
Chevrolet	Spark	2017	2020	AC	
Chevrolet	SS	2014	2020	AC	
Chevrolet	Suburban	2015	2020	AC	
Chevrolet	Tahoe	2015	2020	AC	
Chevrolet	Traverse	2018	2020	AC	
Chevrolet	Trax	2013	2020	AC	
Chevrolet	Volt	2010	2019	AC	
Chrysler	Crossfire	2004	2008	B	

## APPLICATION LIST - NINJA LASER

MAKE	MODEL	START YEAR	END YEAR	CLAMP	ADAPTOR
Dodge	Sprinter	2007	2011	AC	
Ducati	Monster 1100	2009	2020	AC	
Ducati	Monster 796	2011	2020	AC	
Ducati	Streetfighter	2009	2020	AC	
Fiat	500	2012	2015	AC	
Ford	Bronco	2021	2021	AC	
Ford	C-MAX	2013	2019	AC	
Ford	C-MAX Energi	2013	2018	AC	
Ford	C519	2018	2018	AC	
Ford	Crown Victoria	2018	2018	AC	
Ford	Ecosport	2018	2020	AC	
Ford	Edge	2015	2018	AC	
Ford	Escape	2013	2021	AC	
Ford	Expedition	2018	2018	AC	
Ford	Explorer	2016	2021	AC	
Ford	F-150	2015	2021	AC	
Ford	F-250, F-350, F-450	2017	2018	AC	
Ford	F-550, F-650, F-750	2017	2018	AC	
Ford	Fiesta	2011	2020	AC	
Ford	Focus	2012	2020	AC	
Ford	Focus BEV	2012	2017	AC	
Ford	Focus Electric	2012	2014	AC	
Ford	Fusion	2013	2021	AC	
Ford	Mustang	2015	2020	AC	
Ford	Ranger	2019	2019	AC	
Ford	Transit	2015	2020	AC	
Ford	Transit Connect	2010	2013	H	
Genesis	Transit Connect	2014	2020	AC	
Genesis	G70	2019	2020	AC	
Genesis	G80	2021	2021	AC	AD03

## APPLICATION LIST - NINJA LASER

MAKE	MODEL	START YEAR	END YEAR	CLAMP	ADAPTOR
Genesis	G80	2017	2020	AC	
Genesis	G90	2017	2020	AC	
Genesis	GV80	2021	2021	AC	AD03
GMC	Acadia	2017	2020	AC	
GMC	Canyon	2015	2020	AC	
GMC	Savana	2015	2020	AC	
GMC	Sierra	2014	2020	AC	
GMC	Sierra 1500	2014	2020	AC	
GMC	Sierra 2500/3500	2015	2019	AC	
GMC	Terrain	2010	2020	AC	
GMC	Yukon	2015	2020	AC	
Honda	Accord	2003	2020	AC	
Honda	Civic	2003	2020	AC	
Honda	Clarity Electric	2019	2020	AC	
Honda	Crosstour	2010	2017	AC	
Honda	CR-V	2002	2020	AC	
Honda	CR-Z	2011	2016	AC	
Honda	Element	2003	2011	AC	
Honda	FCX Clarity	2008	2020	AC	
Honda	Fit	2007	2020	AC	
Honda	HR-V	2016	2020	AC	
Honda	Insight	2010	2020	AC	
Honda	Odyssey	2005	2020	AC	
Honda	Passport	2019	2020	AC	
Honda	Pilot	2003	2020	AC	
Honda	Ridgeline	2006	2020	AC	AD03
Honda	S2000	2004	2010	AC	AD03
Hyundai	Accent	2012	2020	AC	
Hyundai	Azera	2006	2017	AC	
Hyundai	Centennial	2013	2016	AC	

## APPLICATION LIST - NINJA LASER

MAKE	MODEL	START YEAR	END YEAR	CLAMP	ADAPTOR
Hyundai	Elantra GT	2013	2020	AC	
Hyundai	Elantra Touring	2009	2011	AC	
Hyundai	Equus	2013	2016	AC	
Hyundai	Genesis	2015	2016	AC	
Hyundai	i30	2013	2013	AC	
Hyundai	Ioniq	2017	2020	AC	
Hyundai	Kona	2018	2018	AC	
Hyundai	Nexo	2019	2019	AC	
Hyundai	Palisade (LX2)	2020	2020	AC	
Hyundai	Santa Fe	2013	2020	AC	
Hyundai	Santa Fe Sport	2017	2017	AC	
Hyundai	Sonata	2011	2020	AC	
Hyundai	Sonata Hybrid	2013	2016	AC	
Hyundai	Tucson	2012	2020	AC	
Hyundai	Veloster	2012	2020	AC	
Infiniti	Q45	1990	1996	AC	AD02
Infiniti	QX30	2017	2017	D	AD05
Jaguar	S-Type	1999	2006	H	
Jaguar	X-Type	1988	1999	H	
Jaguar	XJ12	2001	2009	H	
Jaguar	XJ8	2004	2004	H	
Jaguar	XJ	1988	1999	H	
Jaguar	XK	2006	2010	AC	
Jeep	Compass	2018	2020	AC	
Jeep	Gladiator	2020	2020	AC	
Jeep	Renegade	2015	2020	AC	
Jeep	Wrangler	2018	2020	H	
Kia	Amanti	2004	2009	AC	
Kia	Borrego	2009	2010	AC	
Kia	Cadenza	2014	2017	AC	

## APPLICATION LIST - NINJA LASER

MAKE	MODEL	START YEAR	END YEAR	CLAMP	ADAPTOR
Kia	Carnival	2019	2021	AC	
Kia	Forte	2019	2020	AC	
Kia	K900	2015	2016	AC	AD03
Kia	K900 (RJ)	2019	2020	AC	
Kia	Magentis	2010	2016	AC	
Kia	Niro	2017	2020	AC	
Kia	Optima	2010	2020	AC	
Kia	Rio	2010	2020	AC	
Kia	Sedona	2015	2021	AC	
Kia	Sorento	2011	2020	AC	
Kia	Soul	2014	2020	AC	
Kia	Sportage	2012	2019	AC	
KTM	125 Duke	2020	2020	AC	
Land Rover	Discovery 3	2004	2010	AC	
Land Rover	LR3	2004	2010	AC	
Land Rover	Range Rover	2001	2009	AC	
Lexus	CT200h	2011	2017	AC	
Lexus	ES250	1990	1993	AC	
Lexus	ES300	1990	2003	AC	
Lexus	ES330	2004	2007	AC	
Lexus	ES350	2007	2015	AC	
Lexus	GS300	1990	2006	AC	
Lexus	GS350	2007	2007	AC	
Lexus	GS350	2008	2013	AC	
Lexus	GS350	2008	2015	AC	AD03
Lexus	GS400	1992	2007	AC	
Lexus	GS430	2001	2007	AC	
Lexus	GS450	2007	2010	AC	
Lexus	GS450h	2008	2014	AC	AD03
Lexus	GS460	2008	2010	AC	AD03

## APPLICATION LIST - NINJA LASER

MAKE	MODEL	START YEAR	END YEAR	CLAMP	ADAPTOR
Lexus	GX470	2003	2007	AC	
Lexus	IS F	2009	2015	AC	AD03
Lexus	IS250	2008	2015	AC	AD03
Lexus	IS250	2006	2007	AC	
Lexus	IS250C	2010	2011	AC	AD03
Lexus	IS300	2001	2007	AC	
Lexus	IS350	2008	2015	AC	AD03
Lexus	IS350	2006	2007	AC	
Lexus	IS350C	2010	2013	AC	AD03
Lexus	LS400, LS430	1990	2007	AC	
Lexus	LS460	2013	2015	AC	
Lexus	LS500H	2018	2020	AC	
Lexus	LS600H	2013	2014	AC	
Lexus	LX570	2009	2014	AC	
Lexus	NX200/HNX200T	2015	2015	AC	
Lexus	NX300H	2015	2015	AC	
Lexus	RC200t	2016	2017	AC	
Lexus	RX	1999	2010	AC	
Lexus	RX300	1999	2003	AC	
Lexus	RX350	2016	2016	AC	AD03
Lexus	RX350	2010	2015	AC	
Lexus	RX450h	2010	2015	AC	
Lexus	RX450h	2016	2021	AC	AD03
Lincoln	Continental	2017	2020	AC	
Lincoln	Corsair	2020	2020	AC	
Lincoln	MKC	2014	2020	AC	
Lincoln	MKX	2015	2018	AC	
Lincoln	MKZ	2013	2020	AC	
Lincoln	Navigator	2018	2021	AC	
Mazda	Millenia	1995	2002	AC	



## APPLICATION LIST - NINJA LASER

MAKE	MODEL	START YEAR	END YEAR	CLAMP	ADAPTOR
Mercedes	190	1984	1993	D	
Mercedes	200, 230, 250, 260, 280	1979	1986	AC,D	
Mercedes	300, 320, 360, 380	1979	1986	AC,D	
Mercedes	420, 450, 500, 560, 1000	1979	1986	AC,D	
Mercedes	CLK	1998	2013	D	
Mercedes	CLS	1998	2007	D	
Mercedes	SEL	1979	1986	AC,D	
Mercedes	SL	1979	1986	AC,D	
Mercedes	SLC	1979	1986	AC,D	
Mercedes	SLK	1998	2007	D	
Mercedes	SLR	2005	2007	D	
Mercedes	Sprinter	2007	2013	D	
Mercedes	Sprinter	2011	2016	D	AD05
Mercedes	Various B Class	2005	2007	D	
Mercedes	Various C Class	1993	2007	D	
Mercedes	Various E Class	1994	2007	D	
Mercedes	Various G Class	2007	2007	D	
Mercedes	Various M Class	1997	2007	D	
Mercedes	Various Models	2004	2004	D	AD05
Mercedes	Various R Class	2005	2007	D	
Mercedes	Various S Class	1979	1986	D	
Mercedes	Various S Class	1979	1996	AC	
Mercedes	Various S Class	1997	2007	D	
Mercedes	Various SE Class	1979	1996	AC,D	
Mercedes	Various SL Class	1987	1996	AC	AD03
Mercedes	Various SL Class	1997	2007	D	
Mercedes	Vito	2011	2016	D	
MINI	Cooper	2004	2012	AC	
MINI	Cooper S	2004	2012	AC	
Moto Guzzi	Stelvio	2007	2020	AC	AV08

## APPLICATION LIST - NINJA LASER

MAKE	MODEL	START YEAR	END YEAR	CLAMP	ADAPTOR
Pontiac	G8	2008	2009	AC	
Pontiac	GTO	2004	2008	AC	
Porsche	911	1998	2020	AC	
Porsche	912	1999	2020	AC	
Porsche	987	2005	2020	AC	
Porsche	997	2004	2020	AC	
Porsche	Boxter	1996	2016	AC	
Porsche	Cayenne	2003	2020	AC	
Porsche	Cayman	2006	2020	AC	
Porsche	Various Models	2003	2017	AC	
RAM	Promaster	2014	2016	AC	
Saab	Various Models	2008	2017	AC	
Saturn	Astra	2010	2020	AC	
Smart	ForTwo	2007	2020	AC	
Subaru	Ascent	2019	2019	AC	
Subaru	BRZ	2013	2014	AC	
Subaru	Crosstrek	2014	2019	AC	
Subaru	Forester	2009	2019	AC	
Subaru	Impreza	2008	2011	AC	
Subaru	Impreza	2015	2019	AC	
Subaru	Legacy	2010	2019	AC	
Subaru	Outback	2010	2019	AC	
Subaru	WRX/STI	2008	2019	AC	
Toyota	86	2017	2018	AC	
Toyota	4Runner	2012	2018	AC	AD03
Toyota	Avalon	2005	2018	AC	
Toyota	C-HR	2018	2018	AC	
Toyota	Camry	2012	2018	AC	
Toyota	Camry	2006	2018	AC	AD03
Toyota	Camry Hybrid	2006	2018	AC	

## APPLICATION LIST - NINJA LASER

MAKE	MODEL	START YEAR	END YEAR	CLAMP	ADAPTOR
Toyota	Camry XLE	2012	2013	AC	AD03
Toyota	Corolla	2010	2018	AC	AD03
Toyota	Highlander	2011	2018	AC	AD03
Toyota	Land Cruiser	2013	2017	AC	AD03
Toyota	Mirai	2016	2017	AC	
Toyota	Prius	2010	2017	AC	AD03
Toyota	Prius	2012	2017	AC	
Toyota	RAV4	2012	2018	AC	
Toyota	Sequoia	2010	2018	AC	
Toyota	Sienna	2012	2018	AC	AD03
Toyota	Tacoma	2010	2018	AC	
Toyota	Tundra	2010	2018	AC	
Toyota	Venza	2010	2015	AC	AD03
Toyota	Venza	2013	2015	AC	
Volkswagen	Atlas	2018	2020	V	
Volkswagen	Beetle	1998	2013	AC	
Volkswagen	Bora	1998	2005	AC	
Volkswagen	Cabrio	1998	2003	AC	
Volkswagen	Cabriolet	1998	2003	AC	
Volkswagen	Caddy	1999	2005	AC	
Volkswagen	CC	2009	2013	AC	
Volkswagen	Eos	2006	2018	AC	
Volkswagen	Eurovan	2000	2003	AC	
Volkswagen	Fox	2006	2007	AC	
Volkswagen	Golf	1998	2013	AC	
Volkswagen	GTI	1998	2013	AC	
Volkswagen	Jetta	1998	2013	AC	
Volkswagen	Lupo	1998	2005	AC	
Volkswagen	Passat	1996	2018	AC	
Volkswagen	Passat	2019	2020	V	

## APPLICATION LIST - NINJA LASER

MAKE	MODEL	START YEAR	END YEAR	CLAMP	ADAPTOR
Volkswagen	Phaeton	2003	2020	AC	
Volkswagen	Polo	1998	2017	AC	
Volkswagen	Rabbit	2006	2009	AC	
Volkswagen	Tiguan	2017	2020	V	
Volkswagen	Touareg	2000	2013	AC	
Volkswagen	Touran	2003	2017	AC	
Volkswagen	Transporter	2000	2020	AC	
Volvo	760	1988	2009	AC	
Volvo	960	1991	1997	AC	
Volvo	C70	1998	2013	AC	
Volvo	FH Series Truck	1997	2008	B	
Volvo	S40	1999	2004	B	
Volvo	S60	2001	2012	AC	
Volvo	S70	1998	2010	AC	
Volvo	S80	1998	2013	AC	
Volvo	S90	1998	2008	AC	
Volvo	V40	1999	2004	B	
Volvo	V70	1998	2008	AC	
Volvo	V90	1998	1998	AC	
Volvo	XC70	2003	2013	AC	
Volvo	XC90	2003	2013	AC	
Western Star	All Models	1992	2007	AC	