



ASSEMBLY INSTRUCTIONS

- 1. Jack the rear of the cart up and place the frame on jack stands. Place a car jack under the rear end housing of the cart.
- 2. Remove the rear shocks from cart. Save the nuts and bolts for reinstallation.
- 3. The top spring retainer must be removed from the shock. You can either cut the stock spring off the shock with a bench grinder as shown or place the shock in a vice and compress the spring with a screwdriver and pull off the retainer with a set of pliers.
- 4. Once the retainer is removed, slide off stock spring and dispose of it.
- 5. Making sure that the shock is fully extended, slide the new red spring onto shock and replace stock retainer on top of the spring.
- 6. Push spring up tight against retainer and place the 2 piece collar (provided in the kit) in the remaining space between the spring and the bottom of shock.
- 7. Repeat steps 1-5 for second shock.
- 8. Put shocks back on cart.



