



SIDE STEP BRACKETS CLUB CAR® PRECEDENT®

INSTALLATION INSTRUCTIONS

INCLUDED:

U-Bolts
Mounting Brackets
Hardware Pack
Side Steps

TOOLS NEEDED:

Cordless Drill
17mm Socket
17mm Wrench
13mm Socket



NOTE:

Professional installation is recommended. If you choose not to have this product installed by a professional, we highly recommend that you exercise caution, care and patience when installing this product as it involves drilling holes into your cart's body.



STEP 1

Remove and retain factory nuts under frame using 13mm socket.



STEP 2

Install mounting bracket to frame with angled section towards the front. Hand tighten retained hardware.

DO NOT tighten completely until end of the installation. The U-Bolt still needs to be inserted at front of bracket.

Driver Side

STEP 3

Place U-Bolt over front frame and into bracket as shown. Hand tighten nuts and washers.

Driver Side

STEP 4

Now that all mounting hardware is in place, tighten all hardware. Be sure that U-Bolt is tightened evenly as shown.

STEP 5

Attach side step to mounting bracket using 10mm x 55mm bolts. **DO NOT** tighten until all 4 bolts are in place.

REPEAT STEPS 1-5 ON PASSENGER SIDE

INSTALLATION COMPLETE

Club Car[®], Club Car[®] Precedent[®], and Club Car[®] DS[®] are registered trademarks of Ingersoll Rand, Inc. ("Ingersoll Rand"). Reference to Club Car[®], Club Car[®] Precedent[®], or Club Car[®] DS[®] or any of Ingersoll Rand's trademarks, word marks, or products is only for purposes of identifying golf carts with which this product is compatible. These products are aftermarket parts and are not original equipment parts. EXCALIBUR is not connected to, affiliated with, sponsored by, or endorsed by Ingersoll Rand or any of its subsidiary companies.

HARDWARE PACK

PACK 1

2 – Square U-Bolts 10mm x 50mm x 135mm

8 – 10mm x 55mm Hex head bolts


20 – 10mm flat washers

12 – 10mm lock nuts

14-004 - PRECEDENT NERF BAR BRACKETS (GOES w/ 14-001 MJFX ARMOR DROP DOWN SIDE STEP NERF BARS)

WARRANTY PARTS
EXPLODED VIEW DIAGRAM

DIAGRAM SHOWS PASSENGER SIDE BRACKET
(DRIVER SIDE BRACKET IS MIRROR IMAGE)



14-001 - MJFX ARMOR NERF BARS w/ DROP DOWN SIDE STEP (TEXTURED MATTE BLACK)

WARRANTY PARTS
EXPLODED VIEW DIAGRAM

