

1100T/Z1 EVP Turbo to Header Locking Fastener Kit

INCLUDED PARTS

(1) Locking Fastener Kit

REQUIRED TOOLS

8mm Socket

Flat Head Screwdriver

Installation Steps:

Step 1: The tab for the rear PTO bolt will need to be bent over prior to installation. (Figure 1)

Step 2: Install bolts with a washer underneath the header.

Step 3: Torque the bolts and install the locking tabs.

Step 4: Install the “C” clips on each bolt.





INSTALLATION INSTRUCTIONS

Thank you for choosing Evolution Powersports products. If you require further assistance, please call our Tech Support @ (715) 247-3862

Note: This product is exempt from the emission standards and related requirements of 40 C.F.R. § 1051 as provided by 40 C.F.R. § 1051.620, and California law [e.g., vehicle code §§ 27156 and 38391]. This product is sold only for use in connection with EPA certified, purpose-built, nonroad vehicles used solely for closed course, nonroad competition/racing and not used for any recreational purpose or on public highways or right of ways maintained by and open to the public. This product is sold only in connection with machines that do not fall under state and/or federal noise or emission standards/regulations. Purchasers who/that purchase this product represent and warrant that the product is purchased only in connection with EPA -certified, emission-regulations-exempt and noise-regulations-exempt competition/racing vehicles as interpreted under applicable state and/or federal law. Questions: Call Evolution Powersports at (715) 247-3862.

WE'D LOVE TO HEAR FROM YOU - LEAVE A REVIEW & STAY CONNECTED!   