



2020-2021 X3 V-Flow Intake Kit

SKU(s): 203FC0042

INCLUDED PARTS

(1) EVP V-Flow
(1) 3/4-3/4" Nylon Hose Adapter
(1) 80-100 Worm Drive Clamp
(1) 60-40 Worm Drive Clamp
(1) 20-32 Worm Drive Clamp

REQUIRED TOOLS

13mm Socket
7mm Socket
Flat Head Screwdriver



**INSTALLATION STEPS:****Step 1 - Remove air box**

- Use 13mm Socket.
- Remove hose from boost control solenoid on airbox.

Step 2 -Remove clamp from turbo

- Using a flat head screwdriver remove clamp from turbo.

Step 3 - Remove clamp from crank vent tube

- Remove from stock V-Flow.

Step 4 - Insert EVP V-Flow Intake

- Small ID fits to turbo.
- Larger ID fits to air box.
- Attach crank case vent tube to 3/4-3/4" hose adapter.
- Align cut out with barb on airbox.



Thank you for choosing Evolution Powersports products. If you require further assistance, please call our Tech Support @ (715) 247-3862

***Note:** This product is exempt from the emission standards and related requirements of 40 C.F.R. § 1051 as provided by 40 C.F.R. § 1051.620, and California law [e.g., vehicle code §§ 27156 and 38391]. This product is sold only for use in connection with EPA certified, purpose-built, nonroad vehicles used solely for closed course, nonroad competition/racing and not used for any recreational purpose or on public highways or right of ways maintained by and open to the public. This product is sold only in connection with machines that do not fall under state and/or federal noise or emission standards/regulations. Purchasers who/that purchase this product represent and warrant that the product is purchased only in connection with EPA -certified, emission-regulations-exempt and noise-regulations-exempt competition/racing vehicles as interpreted under applicable state and/or federal law. Questions: Call Evolution Powersports at (715) 247-3862.*



INSTALLATION INSTRUCTIONS

WE'D LOVE TO HEAR FROM YOU - LEAVE A REVIEW & STAY CONNECTED!   